

# Engineering Data Sheet

Document No:- 050MR0544D799 rev 13

Installation, Operation & Maintenance Instructions for  
SG Cast Iron wedge gate valves Outside Screw Type

Page 1 of 7

Date 1<sup>st</sup> April 2003

© Hattersley Newman Hender Ltd. 2002

## CE MARKING AND THE PRESSURE EQUIPMENT DIRECTIVE 97/23/EC

This has been implemented in United Kingdom law by the Pressure Equipment Regulations 1999 (SI 1999/2001).

The regulations apply to all valves with a maximum allowable pressure greater than 0.5 bar. Valves with a maximum allowable pressure not exceeding 0.5 bar are outside the scope of the Directive. Valves are categorised in accordance with the maximum working pressure, size and ascending level of hazard, which is dependent on the fluid being transported. Fluids are classified as Group 1, dangerous fluids or Group 2, all other fluids including steam. Categories are SEP (sound engineering practice) and for ascending levels of hazard, I, II, III or IV. All valves designated as SEP do not bear the CE mark nor require a Declaration of Conformity. Categories I, II, III or IV carry the CE mark and require a Declaration of Conformity (Note- all valves up to and including 25mm (1") having a maximum allowable pressure greater than 0.5 bar are designated SEP regardless of fluid group.)

## CE MARKING AND THE ATEX Directive 94/9/EC

### **Concerning equipment and protection systems intended for use in potentially explosive atmospheres.**

This has been implemented in United Kingdom law by the Equipment and Protective Systems Intended for Use in Potentially Explosive Atmospheres Regulations 1996 (SI 1996/192) and amended by The Equipment and Protective Systems (amendment) Regulations 2001 (SI 2001/3766).

The regulations apply to all valves where each valve:

- has its own potential source of ignition.
- operates in a potentially explosive atmosphere created by:
  - o the presence of air / dust mixtures external to the valve.
  - o the presence of gases, vapours, mists released from the valve through leakage.

The regulations will not apply to a valve without a potential source of ignition, which operates in a dust free environment and the fluid being transported is cold, inert gas or non-flammable liquid.

The requisite level of protection for valves not exempt from the regulations is defined as Group II category 2 and shall bear the following marking:

 II 2 GD X

## PRODUCT LIFE CYCLE

The life of the valve is dependent on its application, frequency of use and freedom from misuse. Compatibility with the system into which it is installed must be considered. The properties of the fluid being transported such as pressure, temperature and the nature of the fluid must be taken into account to minimise or avoid premature failure or non-operability. A well-designed system will take into consideration all the factors considered in the valve design, but additionally electrolytic interaction between dissimilar metals in the valve and the system must be examined. Before commissioning a system, it should be flushed to eliminate debris and chemically cleaned as appropriate to eliminate contamination, all of which will prolong the life of the valve.

## LIMITS OF USE

The valves to which these installation, operation and maintenance instructions apply have been:

- a) categorised in accordance with the Pressure Equipment Directive.
- b) designated with the requisite level of protection in the ATEX Directive as Group II Category 2 non-electrical equipment.

# Engineering Data Sheet

Document No:- 050MR0544D799 rev 13

Installation, Operation & Maintenance Instructions for  
SG Cast Iron wedge gate valves Outside Screw Type

Page 2 of 7

Date 1<sup>st</sup> April 2003

© Hattersley Newman Hender Ltd. 2002

These products are categorised for Group 1 Liquid, but are not necessarily suitable for all fluids in this group. Refer to Hattersley Technical Application Engineers for advice. Codes of practice, specifications and regulations should be referred to for specific guidance for valve selection on hazardous service.

Fluid	Group I Liquid		
Fig No.	PN	DN	Category
M552	6	50-150 200-300	SEP I

Fluid	Group I Liquid		
Fig No.	PN	DN	Category
M514	10	50-100 125-300	SEP I

Fluid	Group I Liquid		
Fig No.	PN	DN	Category
544D	3.5 Class 50	2"-10" 12"	SEP I
544E	13.8 Class 100	2"-2½" 3"-5" 6"-12"	SEP I II

Fluid	Group I Liquid		
Fig No.	PN	DN	Category
M544	16	50 65-125 150-300	SEP I II

Fluid	Group I Liquid		
Fig No.	PN	DN	Category
M543	25	50-80 100-150 200-300	I II III

Fluid	Group I Liquid		
Fig No.	PS	DN	Category
504	17.5	2"	SEP
544F	(class 150)	3"-4"	I
A743/743		5"-10"	II
		12"	III

## Operating pressures and temperatures

### PN rated valves

PN	Non-shock pressure at temperature range	Non-shock pressure at max. temperature
6	6 bar from -10°C to 120°C #	5.8bar at 150 °C #
10	10 bar from -10°C to 120°C #	9.2 bar at 180 °C #
16	16 bar from -10°C to 120°C #	14.4 bar at 200 °C #
25	25 bar from -10°C to 120°C #	21.5 bar at 220 °C #

# Engineering Data Sheet

Document No:- 050MR0544D799 rev 13

Installation, Operation & Maintenance Instructions for  
SG Cast Iron wedge gate valves Outside Screw Type

Page 3 of 7

Date 1<sup>st</sup> April 2003

© Hattersley Newman Hender Ltd. 2002

## Class rated valves

	Non-shock pressure at temperature range	Non-shock pressure at max. temperature
Class 50	6.9 bar from -10°C to 40°C #	3.5 bar at 155 °C #
Class 100	13.8 bar from -10°C to 40°C #	6.9 bar at 170 °C #
Class 150	17.5 bar from -10°C to 40°C #	12.8 bar at 220 °C #

Not suitable for fatigue loading, creep conditions, fire testing, fire hazard environment, corrosive or erosive service, transporting fluids with abrasive solids and high velocity gases that can cause shock waves.

# The maximum surface temperature under normal use is given in the table. The auto-ignition temperature of a surrounding potentially explosive atmosphere must exceed the equipment surface temperature by at least 25% (BS EN 1127-1 clause 6.4.2).

## PRESSURE/TEMPERATURE RATING

Valves rated at PN6, PN10, PN16, PN25 and class 150 must be installed in a piping system whose normal pressure and temperature do not exceed the above ratings.

If system testing will subject the valve to pressures in excess of the working pressure rating, this should be within the test pressure for the body with the valve open.

The maximum allowable pressure in valves as specified in the standards is for non-shock conditions. Water hammer and impact for example, should be avoided.

If the limits of use specified in these instructions are exceeded or if the valve is used on applications for which it was not designed, a potential hazard could result.

## LAYOUT AND SITING

It should be considered at the design stage where valves will be located to give access for operation, adjustment, maintenance and repair. Outside screw valves (rising stem) require space above the valve to accommodate the rising stem.

Valves must be provided with adequate support. Adjoining pipework must be supported to avoid the imposition of pipeline strains on the valve body, which would impair its performance.

Heavy valves may need independent support or anchorage.

Gate valves may be installed in:

- a) Horizontal pipework with stem vertical.
- b) Vertical pipework with stem horizontal.

The valve should not be installed in horizontal pipework with the stem horizontal because shut off performance may be impaired.

In the interests of safety, valves installed on end-of-line service in the closed position with infrequent opening should be fitted with a locking device on the operating mechanism. Alternatively, it should be fitted with a blanking flange on the downstream flange of the valve.

---

# Engineering Data Sheet

Document No:- 050MR0544D799 rev 13

Installation, Operation & Maintenance Instructions for  
SG Cast Iron wedge gate valves Outside Screw Type

Page 4 of 7

Date 1<sup>st</sup> April 2003

© Hattersley Newman Hender Ltd. 2002

---

## **INSTALLATION**

Prior to installation, a check of the identification plate and body marking must be made to ensure that the correct valve is being installed. Any electrical component e.g. actuators, limit switches must be explosion proof and comply with the Directive and Standards as listed in BS EN 1127-1 clause 6.4.5.

Valves are precision manufactured items and as such, should not be subjected to misuse such as careless handling, allowing dirt to enter the valve through the end ports, lack of cleaning both valve and system before operation and excessive force during bolting and handwheel operation.

All special packaging material must be removed.

Valves must be provided with adequate support. Adjoining pipework must be supported to avoid the imposition of pipeline strains on the valve body, which would impair its performance.

When large valves are provided with lifting lugs or eye nuts, these should be used to lift the valve.

Valves should not be lifted using the handwheel or stem.

Immediately prior to valve installation, the pipework to which the valve is to be fastened should be checked for cleanliness and freedom from debris.

Valve end protectors should only be permanently removed immediately before installation. The valve interior should be inspected through the end ports to determine whether it is clean and free from foreign matter. The mating flange (both valve and pipework flanges) should be checked for correct gasket contact face, surface finish and condition. If a condition is found which might cause leakage, no attempt to assemble should be made until the condition has been corrected.

The gasket should be suitable for operation conditions or maximum pressure/temperature ratings.

The gaskets should be checked to ensure freedom from defects or damage.

Care should be taken to provide correct alignment of the flanges being assembled. Suitable lubricant on bolt threads should be used. In assembly, bolts are tightened sequentially to make the initial contact of flanges and gaskets flat and parallel, followed by gradual and uniform tightening in an opposite bolting sequence to avoid bending one flange relative to the other, particularly on flanges with raised faces.

Parallel alignment of flanges is especially important in the case of the assembly of a valve into an existing system.

Flanged joints depend on compressive deformation of the gasket material between the flange surfaces.

The bolting must be checked for correct size, length, material and that all connection flange bolt holes are utilized.

At the conclusion of installation and before operating, all dust deposits shall be removed from the equipment..

## **OPERATING**

If a locking device is fitted, the padlock, plate and locking pin should be removed.

The valve is opened by anti-clockwise rotation of the handwheel to a positive stop. Further effort is not necessary. When fully open it is advantageous to rotate the handwheel clockwise 1/2 turn.

To close the valve, the handwheel is rotated clockwise to a positive stop.

---

# Engineering Data Sheet

Document No:- 050MR0544D799 rev 13

Installation, Operation & Maintenance Instructions for  
SG Cast Iron wedge gate valves Outside Screw Type

Page 5 of 7

Date 1<sup>st</sup> April 2003

© Hattersley Newman Hender Ltd. 2002

---

Wheelkeys or other similar devices should not be used.

**Note:-** When the valve is closed at extreme high temperature and then cooled, the wedge may become tight in the valve and prove difficult to open.

Conversely, a valve closed at room temperature can be difficult to open if there is an increase in fluid temperature causing a linear expansion of the stem, which tightens the wedge further into the body seats.

The operator should use suitable hand protection at extreme temperature conditions.

The valve should only be used in the open or closed position.

Regulating or throttling service should be avoided.

## **MAINTENANCE**

The valve should be at zero pressure and ambient temperature prior to any maintenance.

Maintenance Engineers & Operators are reminded to use correct fitting tools and equipment as follows:

Valves within the scope of the ATEX Directive with a protection level defined as Group II category 2 will operate in Zone 1 (gases / vapours) or Zone 21 (dusts) designated in BS EN 1127-1 Explosion prevention and protection. Tools are either 'single spark' e.g. screwdriver, spanner, impact screwdriver or 'shower of sparks' e.g. sawing or grinding. Only steel 'single spark' tools are permissible in Zones 1 and 21.

Tools causing showers of sparks are only permissible if:

- no hazardous explosive atmosphere is present.
- dust deposits have been removed and no dust cloud is present.

The use of tools on equipment in Zones 1 and 21 should be subject to a 'permit to work' system.

A full risk assessment and methodology statement must be compiled prior to any maintenance. This must include the removal of dust deposits by good housekeeping.

The risk assessment must take into account the possibility of the limits of use being exceeded whereby a potential hazard could result.

A maintenance programme should therefore include checks on the development of unforeseen conditions, which could lead to failure.

In systems where corrosion could be a potential hazard, wall thickness checks on the body and bonnet should be made. This requires either the removal of the valve from the pipeline or removal of the bonnet with the system at zero pressure. If the wall thickness has reduced by 25%, the valve must be replaced.

### **Gland Adjustment**

The gland may need adjustment during installation and then periodically thereafter to maintain a stem gland seal. The following procedure is recommended:-

Each gland nut should be tightened evenly in a clockwise direction until increased resistance to operate the valve is obtained, or if leakage is present until the leakage stops.

**Note:-** It is recommended that within the 1st year the gland be inspected at 3 monthly intervals to check for gland leakage.

# Engineering Data Sheet

Document No:- 050MR0544D799 rev 13

Installation, Operation & Maintenance Instructions for  
SG Cast Iron wedge gate valves Outside Screw Type

Page 6 of 7

Date 1<sup>st</sup> April 2003

© Hattersley Newman Hender Ltd. 2002

Under normal working conditions Hattersley Gate Valves should not need further attention but when required the following procedures are recommended.

## Fitting Additional Packing

1. Turn off circulating pumps.
2. Close valve by clockwise rotation of handwheel.
3. Loosen both gland nuts anti-clockwise and remove.
4. Lift the gland flange and gland ring away from gland packing.
5. Fit additional packing by means of wrapping graphite tape packing round stem and pushing packing into stuffing box.
6. Refit the gland ring, gland flange and both nuts, tighten gland nuts evenly in a clockwise direction until increased tension to operate the valve is obtained.

## Replacing Bonnet Gasket

The valve should be isolated from the system and the valve drained before carrying out this operation.

1. Operate valve to mid-position.
2. Loosen and remove series of cap screws from bonnet/body flange (anti-clockwise).
3. Operate valve to closed position (clockwise rotation of handwheel). When closed, operate the valve a further 1/2 to 1 turn, which will break the bonnet joint.
4. Open valve to mid position (anti-clockwise rotation of handwheel).
5. The complete bonnet sub-assembly including the valve wedge can then be lifted off the valve body.
6. Upon reassembly, it is important that the guides on the wedge are located in the body guides.
7. Using a new bonnet gasket, refit the bonnet, cap screws and tighten diagonally to the design/torque requirement as follows:-

SIZE	TORQUE (Nm)
50	34
65	32
80	40
100	81
125	69
150	76
200	130
250	128
300	102

8. Note: It is recommended that the bonnet sub-assembly be refitted complete when the valve body is in line.

For the supply of genuine Hattersley spares, technical assistance or Hattersley ValveServe contact:

---

# Engineering Data Sheet

Installation, Operation & Maintenance Instructions for  
SG Cast Iron wedge gate valves Outside Screw Type

**Document No:-** 050MR0544D799 rev 13

**Page** 7 of 7

**Date** 1<sup>st</sup> April 2003

© Hattersley Newman Hender Ltd. 2002

---

## Hattersley Newman Hender Limited England

Telephone : 01695 577199

Facsimile : 01695 578775

Email : [uksales@hattersley.com](mailto:uksales@hattersley.com)

: [export@hattersley.com](mailto:export@hattersley.com)

Service Freephone : 0500 618205